Lesson 12 Analog Joystick Module

Introduction

In this lesson, you will learn how to use the analog joystick module to add some control in your projects.

Hardware Required

- √ 1 * RexQualis Mega 2560
- √ 1 * Breadboard
- √ 1 * Joystick module
- √ 9 * F-M Jumper Wire

Principle

Analog Joystick Module

The module has 9 pins: 3VCC, 3Ground, X, Y, K.Note that the labels on yours may be slightly different, depending on where you got the module from. The thumb stick is analog and should provide more accurate readings than simple 'directional' joysticks tact use some forms of buttons, or mechanical switches.



Additionally, you can press the joystick down (rather hard on mine) to activate a 'press to select' push-button.

We can use the analog Arduino pin to read the data separately from the X/Y/K pins, Or put it together. The K pin is connected to ground, when the joystick is pressed down, and is floating otherwise. To get stable readings from the K /Select pin, it needs to be connected to VCC via a pull-up resistor. The built in resistors on the Arduino digital pins can be used. For a tutorial on how to

Code interpretation

```
//74HC595 pin 9 STCP
const int SW pin = 3; // input for detecting whether the
jotstick/button is pressed
const int X pin = A0; // analog pin connected to X output
const int Y pin = A1; // analog pin connected to Y output
void setup() {
  pinMode(SW pin, INPUT); //setup SW input
  digitalWrite(SW_pin, HIGH); //reading button state:1=not
pressed,0=pressed
  Serial.begin(9600);
                        //Seput serical connection for
print out to console
} //print out values
void loop() {
  Serial.print("Switch: ");
  Serial.print(digitalRead(SW_pin));
  Serial.print("\n");
  Serial.print("X-axis: ");
  Serial.print(analogRead(X pin));
  Serial.print("\n");
  Serial.print("Y-axis: ");
  Serial.println(analogRead(Y pin));
```

```
Serial.print("\n\n");
delay(2000);
}
```


Experimental Procedures

Step 1:Build the circuit


We need 9 connections to the joystick.

The connections are: K, Y, X, Voltage and Ground.


"Y and X" are Analog and "K" is Digital. If you only need Any one switch then you can use only 3 pins.



Schematic Diagram



Step 2:Open the code:Analog_Joystick_Code




Step 3:Attach Arduino Mega 2560 board to your computer via USB cable and check that the 'Board Type' and 'Serial Port' are set correctly.


Step 4:Upload the code to the RexQualis Mega 2560 board.

Step 5:Open the Serial Monitor then you can see the data as blow:

(How to use the Serial Monitor is introduced in details in Lesson 0 Preface)



Then, Turn the joystick so you can see the data changes on the monitor.



You can see the video of the experiment results on YouTube:
https://youtu.be/WjFCCRq4SrA

If it isn't working, make sure you have assembled the circuit correctly, verified and uploaded the code to your board. For how to upload the code and install the library, check Lesson 0 Preface.